



OWNERS MANUAL


COMPATIBLE WITH THE FOLLOWING CRANES:

PRIZE CUBE JUMBO, PRIZE JUNCTION TRAIN
POLICE CAR


1.800.224.1717

1000 TOWBIN AVE. LAKEWOOD NJ 08701


BEFORE POWER ON



Remove all the ties before power on the machine.




If the claw does not drop, open the front cover and make sure the string goes like this.




There is a small piece of metal on the top of the coil, it will make the strength of the claw a little bit stronger. This item could help to do small adjustment with the strength.

MAIN BOARD DIAGRAM



FAST ADJUSTMENT

Hold the free play button and power on the machine. The display on the control panel will show like below.



The digit on the left is the subject. The three digits on the right are the setting numbers. Move the joy stick to plus or minus the number.

0— Game time(1-99s)



1— Strong claw power(13-48V) (Note: it will be 1/2 on 24V motor machines)



2— Weak claw power(2-47V) (Note: it will be 1/2 on 24V motor machines)



In setting 2, press the catch button the claw will grab the toy.
Lower the voltage until the toy falls. This is the perfect voltage we are looking for.

FAST ADJUSTMENT

- 3— Strong claw power timing(toy drop timing)(0-99ms)



- 4— NOT USED



- 5— Play till win value setting(1-190 games)



- 6— Claw string setting (Push the catch button, the claw will drop automatically to the floor.

Restart the machine to save the setting)



- 7— Auto game start position. Press drop button to test.



- 8— Floor height. Move the joystick to adjust the string length. Press drop button to test.



DIPSWITCH SETTINGS

DIPSW1		1	2	3	4	5	6	7	8
1 COIN=X CREDIT	*1	OFF	OFF						
	2	ON	OFF						
	3	OFF	ON						
	4	ON	ON						
X CREDIT=1 PLAY	*1			OFF	OFF	OFF			
	2			ON	OFF	OFF			
	3			OFF	ON	OFF			
	4			ON	ON	OFF			
	5			OFF	OFF	ON			
	6			ON	OFF	ON			
	2 COINS 3 PLAYS			OFF	ON	ON			
	3 COINS 4 PLAYS			ON	ON	ON			
DIPSW2		1	2	3	4	5	6	7	8
CLAW STOP POINT	*LEFT	OFF							
	RIGHT	ON							
CLAW STOP POINT	BACK		OFF						
	FRONT		ON						
PRIZE EXIT	LEFT			OFF					
	RIGHT			ON					
PRIZE EXIT	BACK				OFF				
	FRONT				ON				
PLAY TILL WIN DATA CLEAN	90s clean					OFF			
	90s not clean (hide)					ON			
GANTRY MODE	*NORMAL						OFF		
	TEST MODE						ON		
GAME MODE	NORMAL							OFF	
	FREE PLAY							ON	
DEMO MUSIC	NO								OFF
	*YES								ON


DIPSWITCH SETTINGS

		*** : DEFAULT							
DIPSW3		1	2	3	4	5	6	7	8
**EXTRA PLAY MACHINE GAME MODE	TILL WIN			OFF	OFF				
	1			ON	OFF				
	2			OFF	ON				
	3			ON	ON				
DISPLAY PLAY TIL WIN GAME TIME	SHOW					OFF			
	HIDE					ON			
GRAB IN AIR	*NO						OFF		
	YES						ON		
NOT USED									
DIPSW4		1	2	3	4	5	6	7	8
NOT USED									
NOT USED									
KEEP THE CREDIT AFTER RESTART	KEEP			OFF					
	CLEAR			ON					
NOT USED									
TICKET EVERY TIME	0					OFF	OFF		
	1					ON	OFF		
	2					OFF	ON		
	3					ON	ON		
MERCY TICKET	0							OFF	OFF
	1							ON	OFF
	2							OFF	ON
	3							ON	ON

WIRING DIAGRAM

COLOR			COLOR			COLOR		
P1 JOYSTICK BUTTON	LEFT	BLUE	P7 COIN2	GND	BLACK	P21 BUTTON LIGHT	GND	BLACK
	RIGHT	BROWN		COIN	WHITE		NONE	NONE
	FRONT	RED	P9 SENSOR	+12V	RED		NONE	NONE
	BACK	ORANGE		IN	BROWN	DROP	YELLOW	
	CLAW	YELLOW	GND	BLACK	NONE	NONE		
P2 VOLTAGE METER	NONE		P11 TICKET	+12V	RED	P22 DISPLAY CN2 GANTRY		
	GND	BLACK		OUT	YELLOW	SP SPEAKER	+	GRAY
P5 COUNTER	GND	BLACK		NONE	NONE			
	+12V	BROWN		+12V	ORANGE			
	PRIZE	WHITE	GND	BLACK				
	+12V	RED	IN	WHITE				
	COIN	ORANGE	P18 POWER SUPPLY	GND	BLACK			
TILT		+5V		BROWN				
NONE		+24V		RED				
P6 COIN1	GND	BLACK		GND	ORANGE			
	COIN	WHITE	+48V	YELLOW				
	+12V	RED	+12V	GREEN				

SENSOR INSTRUCTIONS



Connect to P9 on the board

PS:

1) Make sure four directions around the sensor are painted black. It must be aphotic paint otherwise the sensor may not work properly.

2) Depending on the prize hole size to adjust the distance of the sensor.

A. Red light always on or blinking. Contact Us

B. Green light always or Object stack or Contact Us

TROUBLE SHOOTING

CODE	SITUATION	SELF-EXAMINATION
EP01	U1 ERROR	CHANGE U1
EP02	U8 ERROR	CHANGE U8, OR 4000 XTAL OSC
EP03	MAIN BOARD ERROR	CHANGE U18 OR U23
EC01	COIN SELECTOR 1 ERROR	1. CHECK THE MECHANISM IF IT IS BROKEN 2. CHECK THE COIN STUCK 3. COIN MECH SET IN "NO" MODE
EC02	COIN SELECTOR 2 ERROR	1. CHECK THE MECHANISM IF IT IS BROKEN 2. CHECK THE COIN STUCK 3. COIN MECH SET IN "NO" MODE
AA03	MICRO SWITCH OF LEFT CRANE ERROR	CHECK THE LEFT SWITCH TO SEE IF THE WIRE IS FALLEN OR THE BROKEN
AA04	MICRO SWITCH OF RIGHT CRANE ERROR	CHECK THE RIGHT SWITCH TO SEE IF THE WIRE IS FALLEN OR THE BROKEN
EA01	MICRO SWITCH OF FRONT CRANE ERROR	CHECK THE FRONT SWITCH TO SEE IF THE WIRE IS FALLEN OR LOOSE.
EA02	MICRO SWITCH OF BACK CRANE ERROR	CHECK THE BACK SWITCH TO SEE IF THE WIRE IS FALLEN OR LOOSE.
EE01	MICRO SWITCH WITH WHEEL OF DROP CLAW ERROR	CHECK THE SWITCH WITH WHEEL TO SEE IF THE WIRE IS FALLEN OR LOOSE.
EE02	MICRO SWITCH OF UPPER CLAW ERROR; FUSE BROKEN	1. CHECK 48V FUSE ON THE PCB 2. CHECK CLAW UPPER SWITCH TO SEE IF THE WIRE IS FALLEN OR LOOSE.
EE07	TIP162 WITH METAL COOLER FAILURE	CHANGE THE TIP162
6116	MAIN ROM ERROR	CHANGE 6116
PP01	COIN IN COUNTER ERROR	1. CHECK THE WIRE IF IT LOOSE. 2. CHANGE THE COUNTER
PP02	PRIZE OUT COUNTER ERROR	1. CHECK THE WIRE IF IT LOOSE 2. CHANGE THE COUNTER
EA08 EE99 K1 K2 K1+K2 VR1	DATA ERROR DATA ERROR	PRESS K1+K2 TO RESET PRESS K1+K2 TO RESET AUDIT ACCOUNT NUMERAL TUBE TEST RESET VOLUME
VR2		VOICE VOLUME
VR3		PRONUNCIATION
	THE CLAW CLOSE WHEN POWER TURNS ON.	CHANGE Q17 OR TUP142 TRIODES
	THE GANTRY COULD NOT MOVE PROPERLY.	1. CHECK THE FUSE OF POWER SUPPLY 2. CHECK THE 48V
	CLAW COULD NOT CLOSE DURING THE PLAYING.	1. CHECK THE FUSE OF THE PCB 2. CHECK THE COIL IF IT BURNS OUT
	THERE IS NO ANY FUNCTION WHEN POWER TURNS ON.	CHECK THE FUSE ON THE POWER OUTLET.
	THERE IS NO CREDIT APPEARED	CHANGE THE COIN SELECTOR